

# WEIGL

CONTROL



## Weigl ProCommander LTC


Version 1.09

Menu Plan

# MENU ProCommander Series – LEVEL 1 & 2

## LEVEL 1

## LEVEL 2




Up = Back to the start

Left & Right = Volume/ Navigation


Enter = Press the button to select the displayed function or store value

# MENU ProCommander LTC – MainSetup – LEVEL 2




- ← Left = Back/ one level up
- ⏏ Enter = Press the button to select the displayed function or store value

# MENU ProCommander LTC – Configure – LEVEL 2




- ← Left = Back/ one level up
- ↵ Enter = Press the button to select the displayed function or store value

# MENU ProCommander LTC – Configure – LEVEL 2



- ← Left = Back/ one level up
- ⏏ Enter = Press the button to select the displayed function or store value


# MENU ProCommander LTC – Audio – LEVEL 2




← Left = Back/ one level up

⏏ Enter = Press the button to select the displayed function or store value

# MENU ProCommander LTC – RealTimeClk – LEVEL 2



# MENU ProCommander LTC – Info – LEVEL 2



- ← Left = Back/ one level up
- ⏏ Enter = Press the button to select the displayed function or store value





**[www.WeiglControl.com](http://www.WeiglControl.com) | [Support@WeiglControl.com](mailto:Support@WeiglControl.com)**

**Weigl GmbH & Co KG | +43 650 84 333 48**

Weigl GmbH & Co KG is the hardware manufacturer and distributor worldwide (except Americas)

**Weigl Works, LLC | +1 440 941 5849**

Weigl Works, LLC is the exclusive Americas distributor of Weigl GmbH & Co KG products

**Weigl Support and Solutions Center | [www.Weigl.Support](http://www.Weigl.Support)**

© 2007 - 2016 - Weigl GmbH & Co KG & WeiglWorks, LLC  
Information deemed accurate, but not guaranteed. Subject to change without notice.  
Images used with consent and remain the property of the copyright holder.